



100 ohm

0 ohm jumper

decoupling capacitors

Demuxd signal output (DO2)
CLK used to trigger flipflop
DO2 received from driver

Demuxd signal output (DO1)
CLK, CMD, NTC not used on board
DO1 received from driver

Muxed signal input
DO sent to receiver, converts from LVDS to TTL
DOTTL triggered on flipflop for both channels